



# Alcatel GPON (I-241W-S) Troubleshooting Manual



## Alcatel GPON (with internal router) Model - I-241W-S

4 – Gigabit-Ethernet Ports

2 - POTS Ports


1 – RF-Video Port

1 - USB Port




Alcatel GPON (I-241W-S)

The following figure show the back side of ONT when you can observe the different ports for Ethernet, POTS and RF-TV. Also remember the ports' numbering is from right to left like the Ethernet port nearer to power port is Ethernet Port#1



Port Sequence on Alcatel GPON (I-241W-S)



Light display on Alcatel GPON (I-241W-S) ONT

Indicator	LED Color/Behavior	LED behavior description
<b>Power</b>	Off	Power is Off
	Green Solid	Power is On
<b>WAN</b>	Should be green stable or blinking, else contact NAYAtel Support	
<b>GPON</b>	Should be green stable, otherwise contact NAYAtel Support	
<b>Gigabit-Ethernet</b>	Off	No Ethernet signal detected
	Green flashing	User data going through Gigabit port
	Green Solid	Gigabit interface ready to work
<b>Wi-Fi</b>	Off	No radio signal detected
	Green flashing	User data going through WLAN
	Green Solid	Wi-Fi interface ready to work
<b>WPS</b>	Off	Inactive
	Green Solid	Success Status
	Green flashing	In-progress status
<b>RF-Video</b>	Should be green stable, otherwise contact NAYAtel Support	
<b>VOICE</b>	Off	POTS Inactive
	Green Solid	POTS Active
	Green Blinking	Call in progress

## Precautionary Measures

- 1 – Never remove the power cable from the ONT as this can damage the ONT
- 2 – Never reset ONT by pressing reset button as this will remove all the configurations of the ONT
- 3 – Do not cover the ONT as this blocks the ventilation for the ONT circuitry
- 4 – Only connect the ONT with the UPS provided by Nayatel as other UPS can damage the ONT
- 5 – Donot change the ONT location as it may damage the optical fiber cable. Please contact NAYAtel Support in this regard

## Using Serial Number

Serial number of ONT is a unique number. No two ONTs can have same serial. Customer's User ID can also be identified by this serial number. Serial number is pasted on the front side of ONT.